



TOURATECH

TOURING RALLYE RACING TECHNOLOGY



September 2004

01-044-0630-0

Anleitung Abdeckung Bremslichtschalter R1200 GS

Lieferumfang:

- 1 x Bremslichtschalterabdeckung
- 1 x Linsenkopfschraube Innen6 M5x16
- 1 x U-Scheibe M5
- 1 x Mutter selbstsichernd M5

Entfernen Sie Ihre original BMW Bremslichtschalterabdeckung.

Ersetzen sie die Schraube durch die der Bremslichtschalter befestigt ist durch die beiliegende.

Setzen Sie nun die TT-Abdeckung an Stelle der Originalen und verschrauben Sie diese von hinten mit der mitgelieferten U-Scheibe und der Mutter zunächst handfest.

Richten sie nun bitte die Abdeckung aus, danach können Sie diese nach Herstellerangaben festziehen.

Achtung: Überprüfen sie nach der Montage die Funktion Ihres Bremslichtes.





September 2004

01-044-0630-0

Installation Instructions Brake Light Switch Cover R1200 GS

Contains:

- 1 x Brake light switch cover R1200GS
- 1 x Screw dome head hex M5x16
- 1 x Washer M5
- 1 x Nylock nut M5

Remove first the original BMW brake light switch cover with #25 torx driver.

Lift the plastic tab at the backside to disengage the plastic cover.

Use the supplied M5 screw instead the BMW torx #25 to attach the Touratech cover as well as the washer M5 and Nylock nut M5 on the backside. Tighten finger tight first, align cover and tighten to BMW torque specs.

Test the brake light function after the installation.

