

**Anleitung: Stahlflex-Bremsleitung
hinten Yamaha XT 660 Z Ténéré**
**Instruction: Steel braided brake line,
rear, Yamaha XT 660 Z Ténéré**
Lieferumfang:

 1 x Stahlflex-Bremsleitung hinten mit
Montagematerial

Contents:

 1 x steel braided brake line, rear, with
installation materials

Achtung! Wichtige Hinweise

Alle Schraubverbindungen nach 50Km kontrollieren und nachziehen! Achtung! Bremsflüssigkeit greift Lack an! Bremsanlage muss nach der Montage unbedingt entlüftet werden. Bei unzureichenden Kenntnissen und fehlendem Spezialwerkzeug Bremsleitungen NUR in einer Fachwerkstatt montieren lassen! Leitungen so verlegen, dass diese nicht geknickt und verklemmt werden können!

Attention: important tips, explanations

Check all screws after 50Km and retighten if necessary! Brake fluid attacks the paintwork! It is imperative to bleed the brake system after installation. If you do not have the necessary technical know-how and special tools, have the brake lines fitted ONLY in a professional repair shop! When fitting lines, make sure they cannot be kinked or trapped!

Montage

1. Bremsflüssigkeit ablassen! Hinweis beachten!
2. Blende für Bremszylinder und anschließend die Original-Bremsleitung demontieren
3. Stahlflexleitung wie in Bild 1 mit neuen Dichtscheiben montieren. Achtung! Anziehmomente für die Hohlchrauben entsprechend Betriebsanleitung beachten!
4. Nach der Montage Freigängigkeit der Leitung prüfen und Anlage entlüften!
5. Blende für Bremszylinder wieder montieren!

Assembly

- 1.) Drain the brake fluid. Please pay attention to the notes above.
- 2.) Remove the brake cylinder cover and then remove the original brake line.
- 3.) Fit the steel braided brake line with new sealing washers as shown in Fig. 1. Caution! Observe the tightening torques for the banjo bolts given in the operating manual!
- 4.) After fitting check that the lines move freely and bleed the brake system.
- 5.) Refit the brake cylinder shield.

1

